

INSTALLATION OF “MONOPOLE” ANTENNA KIT

The “monopole antenna kit” can be installed inside or outside the vehicle. In most vehicles, installation of the antenna kit inside the RV is recommended. For trucks, recommended installation of the monopole antenna kit is outside under the vehicle.

All vehicles display unique properties concerning signal interference and reception. Location of the antenna is important for reliable operation. Best reception may require moving the location of the antenna to find the best area for signal reception.

First, screw the blue antenna onto the coax cable. Attach the other end of the coax, (smaller connector on the coax with the elbow) to the plug on the top of the Monitor. Place the monitor near the area you intend to place it and extend the antenna and coax back into the interior of the vehicle. Optimum reception is normally received by placing the antenna as far back in the vehicle as possible.

When installation of the system is complete, it is advised to take a drive to assure all Sensors are reporting faithfully and all signals are being received. Check your monitor for pressure readings. When assured the system is operating properly, place the monitor, antenna & coax in a more permanent location.

If it's necessary to install the antenna outside and under the vehicle, (it is necessary that the antenna have at least 18 inches of clearance from the ground to tip of the antenna for proper reception). Follow the same operation as above - installing antenna temporarily until you are confident the Monitor is picking up all Sensor locations properly. (Install the antenna as far back on the vehicle as possible and centered on the vehicle. It may be necessary to move the antenna slightly to insure best signal reception.)

Happy Motoring!



Pressure
Pro
Tire pressure monitoring systems.

205 W. Wall St . Harrisonville, MO 64701 . Tel: 816-887-3505 . Fax: 816-887-3705